Klima House

Tabel cu specificatiile tehnice ETVX12E6V

					ETVX12S18EA6V	ETVX12S23EA6V	ETVX12S18EJ6V	ETVX12S23EJ6V
Sound pressure level Nom.		dBA	30.0 (6)	30.0 (6)	30.0 (6)	30.0 (6)		
Operation range	Cooling Ambient		Min.	°CDB	0 (7)	0 (7)	0 (7)	0 (7)
		Water side	Max.	°C	0 (7)	0 (7)	0 (7)	0 (7)
			Min.	°C	0 (7)	0 (7)	0 (7)	0 (7)
	Heating	Water side	Max.	°C	0 (7)	0 (7)	0 (7)	0 (7)
			Min.	°C	0 (7)	0 (7)	0 (7)	0 (7)
Sound power level	nd power level Nom.		dBA	44.0 (5)	44.0 (5)	44.0 (5)	44.0 (5)	
Dimensions	Unit Width		mm	595	595	595	595	
			Depth	mm	625	625	625	625
			Height	mm	1,650	1,850	1,650	1,850
Casing	Material			Precoated sheet metal	Precoated sheet metal	Precoated sheet metal	Precoated sheet metal	
Weight	Unit		kg	108	117	108	117	
Electric heater	Recommended fuses A			Α	20 (10)	20 (10)	20.000 (10)	20.000 (10)
	Power supply		Frequency	Hz	50	50	50	50
			Voltage	V	230	230	230	230
			Name		6V3	6V3	6V3	6V3
			Phase		1~/3~	1~/3~	1~/3~	1~/3~
Power supply	Name				See note 9	See note 9	See note 9	See note 9
Notes					to lower flow rates only in case the unit operates with heat pump only. (Not in startup, no BUH operation, no defrost operation). (2) - Based on a dT of 45 K (3) - Including piping + back-up heater; excluding expansion		pump only. (Not in startup, no BUH operation, no defrost operation). (2) - Based on a dT of 45 K (3) - Including piping + back-up heater; excluding expansion	

(4) - Excluding the water in the unit. This minimum water volume is sufficient for most applications. During critical processes extra water may be required.	(4) - Excluding the water in the unit. This minimum water volume is sufficient for most applications. During critical processes extra water may be required.	(4) - Excluding the water in the unit. This minimum water volume is sufficient for most applications. During critical processes extra water may be required.	(4) - Excluding the water in the unit. This minimum water volume is sufficient for most applications. During critical processes extra water may be required.
(5) - Measured with a pressure drop of 10 kPa in the heating system at an operating condition of leaving water 47-55°C in a room with an ambient of 20°C. DB/WB 7°C/6°.	drop of 10 kPa in the heating system at an operating condition of leaving water 47-	drop of 10 kPa in the heating system at an operating condition of leaving water 47-	(5) - Measured with a pressure drop of 10 kPa in the heating system at an operating condition of leaving water 47-55°C in a room with an ambient of 20°C. DB/WB 7°C/6°.
(6) - Value measured in an anechoic room at 1m distance from the unit. It is a relative value, depending on the distance and acoustic environment. The sound pressure level mentioned is measured with a pressure drop	(6) - Value measured in an anechoic room at 1m distance from the unit. It is a relative value, depending on the distance and acoustic environment. The sound pressure level mentioned is measured with a pressure drop	(6) - Value measured in an anechoic room at 1m distance from the unit. It is a relative value, depending on the distance and acoustic environment. The sound pressure level mentioned is measured with a pressure drop	(6) - Value measured in an anechoic room at 1m distance from the unit. It is a relative value, depending on the distance and acoustic environment. The sound pressure level mentioned is measured with a pressure drop of 10 kPa in the heating system at an operatin
	(7) - Refer to operation range of the unit.	(7) - Refer to operation range of the unit.	(7) - Refer to operation range of the unit.
(8) - Depends on operation mode, refer to installation manual.	(8) - Depends on operation mode, refer to installation manual.	(8) - Depends on operation mode, refer to installation manual.	(8) - Depends on operation mode, refer to installation manual.
(9) - Above mentioned power supply of the hydrobox is for the backup heater only. The switch box and the pump of the hydrobox are supplied via the outdoor unit. The optional domestic hot water tank has a separate power supply.	(9) - Above mentioned power supply of the hydrobox is for the backup heater only. The switch box and the pump of the hydrobox are supplied via the outdoor unit. The optional domestic hot water tank has a separate power supply.	(9) - Above mentioned power supply of the hydrobox is for the backup heater only. The switch box and the pump of the hydrobox are supplied via the outdoor unit. The optional domestic hot water tank has a separate power supply.	(9) - Above mentioned power supply of the hydrobox is for the backup heater only. The switch box and the pump of the hydrobox are supplied via the outdoor unit. The optional domestic hot water tank has a separate power supply.
(10) - 4 pole 20 A curve 400V tripping class C (refer to wiring diagram)	(10) - 4 pole 20 A curve 400V tripping class C (refer to wiring diagram)	(10) - 4 pole 20 A curve 400V tripping class C (refer to wiring diagram)	(10) - 4 pole 20 A curve 400V tripping class C (refer to wiring diagram)